


Structure of microfiche



1. Read from left to right
2. Title of microfiche (appears on each coordinate)

E16	Product/component/test step
	Vehicle/engine

Coordinate

3. Limits of section



Beginning



Mid-section



End



One-page section

4. References to relevant test steps in test specifications; coordinate e.g. C6

C6

A1	Trouble-shooting program	
-----------	--------------------------	--

1. Special features

Vehicles with:	Control unit	0 227 100 124 (with current limiter)
	Ignition coil	0 221 122 334
	Anti-knock control unit	0 261 201 004
	Knock sensor	0 261 231 001

2. Test values

Dwell angle at starting speed	27 ... 33%	B21
-------------------------------	------------	------------

Ignition coil primary	0.6...1.0 Ω	B17
Ignition coil secondary	6.4...11.1 k Ω	

Basic ignition setting at idle	12 \pm 1° before TDC 700...800 min ⁻¹	C7
-----------------------------------	---	-----------

Anti-boilover switch	> approx. 103°C, approx. 0 Ω < approx. 103°C, approx. ∞ Ω	C9
----------------------	---	-----------

Timing angle at idle (Anti-boilover switch bridged)	23...27° before TDC	C13
---	---------------------	------------

Voltage to anti-knock control unit	\geq 10.5V	C15
---------------------------------------	--------------	------------

Knock sensor	270...330 k Ω	C21
Knock sensor tightening torque	11 ... 15 Nm	

A2

Test values

Volvo



Test values (cont'd.)

Voltage to control unit 12 ... 14 V

D3

Voltage to ignition coil ≥ 10 V

Primary voltage at idle 295 ... 365 V

D5

Voltage to magnetic pulse generator with ignition on ≥ 9 V


E7

See auto data test values for setting values for timing, idle speed, exhaust, valve clearance, etc.

A3

Test values
Volvo





⚡ = high voltage
(400 V - 25 kV)

1 = Anti-knock control unit
2 = Ignition distributor
(magnetic pulse generator)
3 = Control unit

4 = Knock sensor
5 = Ignition coil
5a = To ignition distributor
6 = Diagnostic connector
7 = LH-Jetronic control unit

8 = Throttle valve switch
9 = Fan motor
10 = Anti-boilover switch
11 = Ignition/starter switch
12 = Battery

3. Wiring diagram

A4

Wiring diagram
Volvo




A5

Wiring diagram
Volvo



227/366



1 = Control unit


2 = Diagnostic connector

4. Component locations

The control unit is mounted on a heat sink inside the engine compartment (near left-hand wheel well).

The diagnostic connector is located on the wiring harness.






1 = Anti-boilover switch

A7

Component locations

Volvo






1 = Fan motor (anti-boilover protection)

A8

Component locations
Volvo





Throttle valve switch

A9

Component locations
Volvo





1 = Knock sensor

The knock sensor is located on the upper part of the engine block (driver's side).

Note:

See above for correct position of knock sensor (connection on side).

Attach mounting bolt of knock sensor w i t h o u t plain washer, spring lock washer, tooth lock washer, etc.

Tightening torque 11 ... 15 Nm


Secure mounting bolt only with locking paint.




The anti-knock control unit is located inside the cabin at the left near the pedal mechanisms. See photograph below.

Removal instructions:

Remove steering column cover panel. See arrow in photograph above.



1 = Anti-knock control unit



A11

Component locations
Volvo



A12

Component locations
Volvo




The LH-Jetronic control unit is located inside the cabin at the right (below the glove compartment). See photograph below.

Removal instructions:


Remove mounting screws from door threshold molding and LH-Jetronic control unit cover. See arrow in photograph above.

Remove cover and molding. See photograph above.



1 = Door threshold molding
2 = LH-Jetronic control unit cover

1 = LH-Jetronic control unit



A13

Component locations
Volvo



A14

Component locations
Volvo



5. Required test instruments and tools

Engine tester, e.g.	MOT 201	0 684 000 201
Spark discharge tester, e.g.		
Ignition coil condenser tester	EFAW 106 A	0 681 100 001
or		
Single spark discharge tester	EF 1177 / 7	1 684 531 000
5 k Ω sleeve-type suppressor		0 356 500 001
Ohmmeter	ETE 014.00	0 684 101 400
or	Pontavi WH 2	commercially available
Voltmeter, e.g.	ETE 014.00	0 684 101 400
Analog voltmeter (multimeter) for determining self-diagnosis voltage pulses		commercially available
Test leads (for proper attachment of test equipment to connectors)		KDZS 0004
Test prods (for proper attachment of test equipment to connectors)		commercially available
Thermal conduction paste		5 942 860 003
Bolt locking paint, 30 g		5 703 245 003
Torque wrench		commercially available
Range: 5 ... 60 Nm		
Auxiliary lead for user fabrication (e.g. to check anti-boilover function)		
Parts required:		
approx. 90 mm of 1.5 mm ² cable		6 210 ...
2 flat pin terminals		8 784 480 011



6. Incorrect speed, dwell angle and firing point display

Incorrect indication of speed, dwell angle and firing point by test equipment may occur in ignition systems with control unit 0 227 100 124 (TZ-I) incorporating current limitation.

See coordinates N 10 - N 14 for additional information.

7. Hazards in electronic ignition systems

Increased demands placed on ignition systems by modern engines, as well as the desire for reduced maintenance, caused electronic ignition systems to be introduced as standard equipment some time ago.

As a rule, the power supplied by nearly all electronic ignition systems exceeds that of conventional systems, and further increases are expected. Thus electronic ignition systems are within a power range where contact with live parts or terminals can be extremely hazardous (on both the primary and secondary sides).

We therefore recommend that any work or tests performed on the ignition system be in accordance with VDE Regulations (Association of German Electrical Engineers), particularly VDE 0104 dated July, 1967, as well as all pertinent national regulations.



The ignition must always be switched off when work is performed on the ignition system (switch off ignition and/or power supply).


This work includes:

- attaching engine testers (timing light, dwell-tach tester, ignition oscilloscope, etc.)
- replacing ignition system parts (spark plug, ignition coil, ignition distributor, ignition cable, etc.)

Should testing of the ignition system or adjustments to the engine (e.g. LH-Jetronic) require the ignition to be switched on (switch on ignition or power supply), the high voltages mentioned above will be present throughout the entire system.

Hazards therefore exist not only within the individual subassemblies of the ignition system (e.g. ignition distributor, ignition coil, control unit, ignition harness), but also at the wiring harness (e.g. tachometer connector, diagnostic connector), plug connection cables and test equipment.





⚡ = high voltage
(400 V - 25 kV)

1 = Anti-knock control unit
2 = Ignition distributor
(magnetic pulse generator)
3 = Control unit

4 = Knock sensor
5 = Ignition coil
5a = To ignition distributor
6 = Diagnostic connector
7 = LH-Jetronic control unit

8 = Throttle valve switch
9 = Fan motor
10 = Anti-boilover switch
11 = Ignition/starter switch
12 = Battery

Using the wiring diagram of an electronic ignition system as an example, hazardous points are marked with high-voltage arrows.

A18

Hazards
Volvo



A19

Hazards
Volvo



8. Important vehicle information


- Conduct resistance measurements only with ignition switched off or battery disconnected (tester defective)
- During compression testing remove control unit plug, or using an auxiliary cable securely connect ignition coil terminal 4 to ground (dangerously high voltage, insulation damage on ignition coil, ignition distributor, ignition harness).

Note:

Auxiliary cable must have at least 2 k Ω suppression, e.g. 5 k Ω sleeve-type suppressor 0 356 500 001.

- Do not replace specified ignition coil (see part No.) with a different type of ignition coil.
- Do not connect a suppression capacitor to ignition coil terminal 1.
- Do not connect ignition coil terminal 1 to ground as an anti-theft measure (when ignition is switched "on" ignition coil will be destroyed).
- Do not connect a positive battery terminal or test lamp to ignition coil terminal 1 (control unit will be destroyed).
- Do not remove the high voltage ignition cable between ignition coil terminal 4 and ignition distributor terminal 4 with the engine running.
- Flashover from ignition coil terminal 4 to ignition coil terminals 1 and 15 must be prevented. The magnetic pulse generator and control unit could be destroyed.





1 = Control unit


2 = Baseplate

- Coat baseplate with thermal conduction paste before mounting control unit.

Use only suitable object (screwdriver, match, etc.) to apply paste.

Keep thermal conduction paste off painted parts.






1 = Spark discharge tester

3 = Ignition coil

2 = 5 kΩ sleeve-type suppressor

 = High voltage (400 V - 25 kV)

- To prevent damage to the control unit when using a spark discharge tester, a suppression resistor of at least 2 kΩ must be connected between the spark discharge tester and ignition coil terminal 4 (e.g. 5 kΩ sleeve-type suppressor 0 356 500 001) to prevent damage to the control unit.



prevent damage to the control unit, a suppression resistance of at least 2 k Ω must be connected to the secondary side of the ignition system. The original distributor rotor must be installed with a 1 k Ω suppression resistor (also do not use a 5 k Ω distributor rotor for radio interference suppression).

- Do not attach any external voltage source such as an ohmmeter to the magnetic pulse generator (hall generator). Use caution when switching meter ranges.
- Leads running from the magnetic pulse generator to the anti-knock control unit or from the anti-knock control unit to the control unit must be shielded (to prevent disruption of anti-knock control unit or control unit operation).
- Do not allow the ignition distributor cap holding springs to fall into the generator system while cranking the engine with the dust protection cover removed.
- Flashover or punchthrough at ignition distributor cap (poor insulation) may destroy the magnetic pulse generator and the control unit.
- Do not disconnect battery terminals with engine running.
- Do not assist starting at more than 16 volts or with a fast charger.
- Reversed battery polarity will destroy the magnetic pulse generator, control unit, ignition coil and anti-knock control unit.
- Knock sensor cable must be shielded and routed separate from high voltage cables.
- Attach mounting bolt of knock sensor w i t h o u t plain washer, spring lock washer, tooth lock washer, etc. Secure mounting bolt only with locking paint.



9. Troubleshooting

9.1 Using the self-diagnosis system and the self-diagnosis test chart

This vehicle has a built-in anti-knock control unit which contains a self-diagnosis system (only for knock regulation).

Therefore every test conducted with the engine running must begin with the self-diagnosis system.

Coordinates B5/B6 describe how to activate the system.

The self-diagnosis test chart which begins at coordinates B7/B8 identifies trouble indicators (in the form of voltage pulses), causes of trouble and test procedures, and gives the coordinates for more specific troubleshooting.

If the self-diagnosis system indicates no trouble but the cause of the customer's complaint has not been eliminated, continue the troubleshooting procedure in accordance with the troubleshooting chart and the troubleshooting sequence beginning at coordinate B 9.

9.2 Using the troubleshooting chart

The troubleshooting chart beginning at coordinate B9 lists customer complaints (symptoms), causes of trouble, test procedures and reference coordinates.

Select the possible cause of the trouble which corresponds to the customer's complaint as indicated in the troubleshooting chart.

If the cause of the trouble is unclear, begin testing using the extensive, self-contained troubleshooting sequence beginning at coordinate B 15.

If the cause of the trouble can be clearly determined according to the troubleshooting chart, the problem can be pinpointed using the given coordinates without having to go through the entire troubleshooting sequence for each problem.

If no coordinates are given, proceed with troubleshooting using the "test steps" column.

9.3 Using the troubleshooting sequence

The troubleshooting sequence beginning at coordinate B 15 is divided into 3 columns:

The left-hand column gives test steps and test values.

The center column gives instructions for repair.

The right-hand column contains the corresponding figures and wiring diagrams and indicates their locations.

If the questions given in the left-hand column can be answered "yes", go on to the next test directly below.

If a question is answered "no", move over to the center column and conduct the tests listed there.

9.4 Testing requirements

Battery fully charged, fuel system OK, engine in good working order (compression, valve clearance, etc.), ambient temperature or temperature of ignition system between 0 and 100°C (temperature has pronounced effect on measurements).

9.5 Activating the self-diagnosis system

Test requirement: engine speed of at least $3,500 \text{ min}^{-1}$

General

Anti-knock control unit 0 261 201 004 has a self-diagnosis system with a diagnostic connector located in the engine compartment.

See photograph.

The self-diagnosis system only indicates one fault at a time.

The first fault must be eliminated before any subsequent faults can be indicated.

A total of 4 different faults (only for knock regulation) in the form of voltage pulses can be determined. The voltage pulses are displayed on an ANALOG VOLTMETER (with pointer) as pointer deflections.

The person conducting the test counts the voltage pulses (pointer deflections indicated on the voltmeter).

Voltmeters with a digital display cannot be used!

Activating the system

Connect voltmeter to positive battery terminal and diagnostic connector. See photograph.

Switch on ignition.

The voltmeter must indicate the approximate battery voltage. If no battery voltage is indicated, follow test steps at coordinates C 1/C 2. Then continue activation procedure in accordance with coordinates B 5/B 6.


Start the engine, run up to at least $3,500 \text{ min}^{-1}$ and then run at idle.

Depending on the fault involved, the voltmeter will now show 2 to 5 voltage pulses. By referring to the self-diagnosis test chart (coordinates B 7/B 8), the faults can be evaluated and eliminated.

Note: A pause follows each diagnostic sequence (voltmeter pointer remains at "zero").


The diagnostic sequence, including pauses, is repeated until the ignition is switched off, thus clearing the fault indication stored in the anti-knock control unit.

Self-diagnosis activation followed by elimination of the fault must be repeated until no voltage pulses are indicated (knock regulation is then OK).



1 = Diagnostic connector

- 1 = Diagnostic connector
- 2 = Analog voltmeter
- 3 = Positive battery terminal



B5

Self-diagnosis system

Volvo



B6

Self-diagnosis system

Volvo



Self-diagnosis test chart

Trouble indication	Cause of trouble	Test steps	Coordinates
No voltage pulse	Anti-knock control unit OK	-----	-----
2 voltage pulses	Supply voltage from knock regulator 10.5 V	Check for voltage drop and eliminate	C 15
3 voltage pulses	Anti-knock control unit (evaluation circuit) not OK	Replace anti-knock control unit	-----
4 voltage pulses	Anti-knock control unit not OK	Check knock sensor (sensor mounting, opens and shorts)	C 19
5 voltage pulses	Load signal (LH-Jetronic) not OK	Check load signal	C 23

B7

Self-diagnosis system

Volvo



B8

Self-diagnosis system

Volvo



9.6 Troubleshooting chart

Customer complaint (symptom)

1. Starter engages, engine does not start

2. Rough idle

3. Engine gets no gas (flow problem)

4. Poor engine performance

5. Engine misfires

6. Fuel consumption too high

7. Engine pings or knocks

8. Faulty ignition

9. Engine runs too hot

									Cause of trouble	Test steps	Coordinates
●	●	●	●	●	●	●	●	●	Unclear	Perform thorough troubleshooting	B 15
●	●	●	●	●	●		●		Spark plugs defective	Evaluate ignition oscilloscope trace or remove and visually check spark plug	----
		●	●	●	●				Suppression resistors defective	Evaluate oscilloscope trace or measure resistance	----
●	●	●	●	●					Shunt on secondary side	Check ignition coil, ignition distributor, ignition harness and spark plug by means of oscilloscope trace or visual check	----
●	●	●	●	●					Open circuit on secondary side	Check ignition coil, ignition distributor, ignition harness and spark plug by means of oscilloscope trace or check continuity using ohmmeter	----
●									Open circuit on primary side	---	E 1
●	●	●	●	●					Ignition coil defective	---	B 17

B9

Troubleshooting chart

Volvo



B10

Troubleshooting chart

Volvo



Troubleshooting chart

Customer complaint (symptom)

1. Starter engages, engine does not start

2. Rough idle

3. Engine gets no gas (flow problem)

4. Poor engine performance

5. Engine misfires

6. Fuel consumption too high

7. Engine pings or knocks

8. Faulty ignition

9. Engine runs too hot

									Cause of trouble*	Test steps	Coordinates
●	●						●		Firing sequence incorrect	Firing sequence 1 - 3 - 4 - 2	----
	●								Throttle valve switch idle contact defective	----	C 3
●	●	●	●	●	●	●		●	Ignition timing adjustment incorrect	----	C 7
								●	Anti-boilover switch defective	----	C 9
								●	Fan motor defective	----	C 11
								●	Anti-boilover function not operating	----	C 13
●			●		●				Power supply from anti-knock control unit incorrect	----	C 15

B11

Troubleshooting chart

Volvo



B12

Troubleshooting chart

Volvo



Troubleshooting chart

Customer complaint (symptom)

1. Starter engages, engine does not start
2. Rough idle
3. Engine gets no gas (flow problem)
4. Poor engine performance
5. Engine misfires
6. Fuel consumption too high
7. Engine pings or knocks
8. Faulty ignition
9. Engine runs too hot

									Cause of trouble	Test steps	Coordinates
			●		●				Knock sensor defective	---	C 19
		●	●		●				Load signal from LH-Jetronic incorrect	---	C 23
●									Power supply from control unit incorrect	---	E 1
●			●		●				Power supply from anti-knock control unit incorrect	---	E 3
●									Magnetic pulse generator defective	---	E 5
●									Anti-knock control unit incorrect	---	E 11
			●		●				Abnormal engine noise	Engine has mechanical problems (bearing damage, broken valve spring, etc.)	----
			●		●	●			Improper fuel	Fuel octane too low	----

B 13

Troubleshooting chart

Volvo



B 14

Troubleshooting chart

Volvo



9.7 Troubleshooting sequence

Check primary signal.

If oscilloscope or tachometer tester not available, check for ignition spark on spark discharge tester.

Primary signal with oscilloscope

Connect oscilloscope to ignition coil as per operating instructions. Start engine. Oscilloscope must indicate primary voltage (magnitude not important).

Primary signal with tachometer tester

Connect tachometer tester to ignition coil as per operating instructions. Start engine. Tachometer tester must register a value (magnitude not important).

Ignition spark with spark discharge tester

Remove high tension ignition cable at terminal 4 of ignition coil.
Connect spark discharge tester with sleeve-type suppressor (5 k Ω) to ignition coil.
Set spark gap to 5 mm.
Start engine.
Sparks must appear across spark gap.

Are primary signal and/or ignition sparks in spark gap present?


yes

Continued at B 17/B 18

no

If no primary signal or ignition spark is present, continue test at coordinate E 1.

Test beginning at B 17 not necessary.



- 1 = Spark discharge tester
- 2 = 5 k Ω sleeve-type suppressor
- 3 = Ignition coil

⚡ = high voltage

B 15



Troubleshooting sequence
Volvo



B 16



Troubleshooting sequence
Volvo





1 = Plug
2 = Protective cap





Continued

Step 2

Disconnect positive and negative battery cables.
Remove control unit connector.
Switch on ignition.

Check leads from positive battery terminal to control unit connector terminal 4 and from negative battery terminal to control unit connector terminal 2 for contact resistance.
Max. total contact resistance 0.3Ω (allow for resistance of test leads and test prods).
Eliminate contact resistance.

Check leads from positive battery terminal to ignition coil terminal 15 and the lead from ignition coil terminal 1 to control unit connector terminal 1 for contact resistance.
Max. total contact resistance 0.3Ω (allow for resistance of test leads and test prods).
Eliminate contact resistance.

Step 3


Reconnect battery. Attach dwell angle tester to ignition coil as per operating instructions.
Start engine. Dwell angle tester must indicate 27 ... 33% (only during starting). If dwell angle is incorrect, replace anti-knock control unit.

If steps 1, 2 and 3 were OK, replace control unit.

yes


Continued at C 1/C 2

Continued at B 23/B 24



8 = Control unit connector

1 = Anti-knock control unit



B21

Troubleshooting sequence

Volvo



B22

Troubleshooting sequence

Volvo



Continued

Step 4

Unplug LH-Jetronic control unit connector. See arrow in top photograph.

Set oscilloscope to "special" setting and attach as per operating instructions.

Example: MOT 201

Connect red clip with test prod to LH-Jetronic connector terminal 1 (test signal). See top photograph.

Connect black clip to vehicle ground.

Start engine.

Oscilloscope must display a square wave. See center illustration.

If square wave is not displayed, unplug anti-knock control unit connector. See bottom photograph.




Check continuity of lead from anti-knock control unit connector terminal 2 to LH-Jetronic control unit connector terminal 1.

Eliminate discontinuity.

If no discontinuity is found, replace anti-knock control unit.

yes

Continued at C 1/C 2



B 23



Troubleshooting sequence
Volvo



B 24


Troubleshooting sequence
Volvo





1 = Diagnostic connector
2 = Analog voltmeter
3 = Positive battery terminal

9 = Anti-knock control unit connector



C1

Troubleshooting sequence

Volvo





C2

Troubleshooting sequence


Volvo





Throttle valve switch connector

9 = Anti-knock control unit connector



C3

Troubleshooting sequence
Volvo



C4

Troubleshooting sequence
Volvo



Continued

Attach throttle valve switch connector.

Connect voltmeter to terminals 1 (positive) and 4 (negative) of unplugged anti-knock control unit connector.

Switch on ignition.

Loosen mounting bolts of throttle valve switch slightly (see arrow, bottom photograph) and rotate the switch until the idle contact audibly clicks and the voltmeter indicates approximately the battery voltage.

If no battery voltage is indicated, replace the throttle valve switch.

Adjustment check:


Open throttle valve slightly.

Idle contact must click audibly.

Voltmeter must indicate 0 V.


yes

Continued at C 7/C 8



9 = Anti-knock control unit connector

Throttle valve switch



C5

Troubleshooting sequence

Volvo



C6

Troubleshooting sequence

Volvo



yes

Check ignition timing adjustment.

Remove non-insulated connector from anti-boilover switch. See top photograph.

Start engine and briefly run up to $>1000 \text{ min}^{-1}$. Then run at idle ($700 \dots 800 \text{ min}^{-1}$).

Caution:

Throttle valve switch (idle contact) must be closed. (If the test equipment indicates an obviously incorrect speed, connect a dropping resistor in series or make necessary conversion to the engine tester.)

Check timing mark with timing light.

Ignition timing adjustment must be $12 \pm 1^\circ$ before TDC. See bottom photograph.


Is ignition timing adjustment OK?

no

Loosen ignition distributor mount and turn distributor in advance direction to $12 \pm 1^\circ$ before TDC.


yes

Continued at C 9/C 10



1 = Anti-boilover switch
2 = Connector (not insulated)

Timing mark



C7


Troubleshooting sequence
Volvo



C8



Troubleshooting sequence
Volvo





- 1 = Anti-boilover switch
- 2 = Anti-boilover switch connector
- 3 = Auxiliary lead

- 9 = Anti-knock control unit connector



C9

Troubleshooting sequence
Volvo



C10



Troubleshooting sequence
Volvo





- 1 = Anti-boilover switch
- 2 = Anti-boilover switch connector
- 3 = Auxiliary lead

Fan motor



yes

Check anti-boilover function

Remove both anti-boilover switch connectors and bridge them with an auxiliary lead. See top photograph.

Start engine and briefly run up to $>1000 \text{ min}^{-1}$. Then run at idle.

(If the test equipment indicates an obviously incorrect speed, connect a dropping resistor in series or make necessary conversion to the engine tester.)

Check timing mark with timing light.

Timing angle must be $23 \dots 27^\circ$ before TDC.


Is timing angle correct?

no

Replace anti-knock control unit.


yes

Continued at C 15/C 16



- 1 = Anti-boilover switch
- 2 = Anti-boilover switch connector
- 3 = Auxiliary lead

Timing mark



C13



Troubleshooting sequence
Volvo



C14


Troubleshooting sequence
Volvo





1 = Handle cover
2 = Fastening screw

1 = Anti-knock control unit
2 = Anti-knock control unit connector




Continued

3. If no voltage drop is measured under 1 and 2 above, replace anti-knock control unit.

yes

Continued at C 19/C 20,



1 = Anti-knock control unit

C17


Troubleshooting sequence
Volvo





C18

Troubleshooting sequence
Volvo





1 = Male knock sensor connector
2 = Female knock sensor connector



Continued

Switch off ignition.

Unplug knock sensor and anti-knock control unit connectors.

2. Attach ohmmeter between:
knock sensor connector anti-knock control unit connector

term. 8 and term. 8

term. 15 and term. 15

Ohmmeter must indicate approx. 0Ω (continuity).

Eliminate discontinuity.

3. Attach ohmmeter between:
knock sensor connector anti-knock control unit connector

term. 8 and term. 11

Ohmmeter must indicate $\infty\Omega$.

If ohmmeter indicates approx. 0Ω , (continuity), eliminate short to ground in knock sensor lead between terminals 8 and 11.

4. Reconnect knock sensor connector; attach ohmmeter between:
knock sensor connector anti-knock control unit connector

term. 8 and term. 15

Ohmmeter must indicate

270 ... 330k Ω .


If resistance values not OK, replace knock sensor.

5. Check tightening torque of knock sensor mounting bolt (11 ... 15 Nm).

If steps 1 through 5 OK, replace knock sensor.


yes

Continued at C 23/C 24



Knock sensor connector

9 = Anti-knock control unit connector



C21

Troubleshooting sequence

Volvo





C22

Troubleshooting sequence


Volvo





1 = Handle cover
2 = Fastening screw

1 = Anti-knock control unit
2 = Anti-knock control unit connector



C23

Troubleshooting sequence
Volvo



C24

Troubleshooting sequence
Volvo



Continued

If 0 V is indicated:

Switch off ignition and unplug anti-knock control unit and LH-Jetronic control unit connectors.


Check lead between anti-knock control unit connector terminal 14 and LH-Jetronic control unit connector terminal 24 for continuity.

Eliminate discontinuity.

If there is no discontinuity, replace LH-Jetronic control unit.


yes

Continued at D 3/D 4



9 = Anti-knock control unit
connector
connector

LH-Jetronic control unit
connector



D1

Troubleshooting sequence

Volvo





D2

Troubleshooting sequence

Volvo





8 = Control unit connector

D3



Troubleshooting sequence
Volvo



D4

Troubleshooting sequence
Volvo






D5



Troubleshooting sequence
Volvo






D6

Troubleshooting sequence
Volvo





8 = Control unit connector



9 = Anti-knock control unit connector

yes

Check male and female halves of ignition distributor connector.

Press wire retainer of ignition distributor connector (arrow).

Unplug ignition distributor connector.

Visual check:

Check male and female contacts of ignition distributor connector for oxidation.

Remove oxidation.


Reconnect ignition distributor connector.

Start engine.

If no primary signal or ignition spark, continue test.


yes

Continued at E 7/E 8



1 = Male ignition distributor connector

2 = Female ignition distributor connector



E5

Troubleshooting sequence

Volvo





E6

Troubleshooting sequence


Volvo





6 = Ignition distributor connector
6a = Wire retainer

9 = Anti-knock control unit connector



E7

Troubleshooting sequence
Volvo



E8

Troubleshooting sequence
Volvo



yes

Check operation of magnetic pulse generator.

Anti-knock control unit and ignition distributor connectors are connected.

Pull back rubber sleeve on ignition distributor connector.

Connect oscilloscope set to "special" range as per operating instructions.

For example MOT 201:

Connect red lead to ignition distributor connector terminal 6 (test signal).

Connect black lead to ground.

Start engine.

Oscilloscope must display a square wave. See illustration.


Is square wave displayed?

no

Replace magnetic pulse generator or ignition distributor.

yes


Continued at E 11/E 12



6 = Ignition distributor connector

6a = Wire retainer

Square wave



E9


Troubleshooting sequence
Volvo




E10

Troubleshooting sequence
Volvo





Square wave



E11

Troubleshooting sequence
Volvo



E12

Troubleshooting sequence
Volvo



Continued

Connect ohmmeter to the following one after the other:

Control unit
connector

term. 6
term. 5

Anti-knock
control unit
connector

and term. 9
and term. 9


Ohmmeter must indicate approx. 0Ω
(continuity) in each case.

Eliminate discontinuity.

If no discontinuity is found, replace
anti-knock control unit.


yes

Continued at E 15/E 16



9 = Anti-knock control unit
connector

8 = Control unit connector



E13

Troubleshooting sequence
Volvo



E14

Troubleshooting sequence
Volvo



yes

Check ignition coil.

Visual check:

Remove protective cap from ignition coil and check for missing plug (see illustration) and leakage of sealing compound.

Electrical check:

Primary ignition coil winding
(term. 15 and term. 1) 0.6 ... 1.0 Ω .
(Allow for resistance of instrument lead and test prods.)

Secondary ignition coil winding
(term. 1 and term. 4) 6.4 ... 11.1 Ω .

Plug present and no leakage of sealing compound?

Is resistance value OK?

no

1. If plug is missing or sealing compound has leaked, replace control unit, anti-knock control unit and ignition coil.
2. If resistance values are not OK, replace ignition coil.

yes


Replace control unit.

Test completed.

Tests at B 17 not necessary.

Note:

If customer complaint still exists, problem may be in fuel system or engine may have mechanical problem.



1 = Plug
2 = Protective cap

E15

Troubleshooting sequence

Volvo



E16

Troubleshooting sequence

Volvo



After-sales Service

Technical Bulletin

Only for use within the Bosch organization. Not to be communicated to any third party.

22

Danger of Accident on Semi-conductor Ignition Systems

VDT-I-227/102 B

11.1976

Please be sure to pass this bulletin on to your employees for their attention.

The increased demands made on their ignition systems by modern engines, and the wish for freedom from maintenance, led some time ago to manufactures starting to equip their vehicles with semi-conductor ignition systems as original equipment. In most cases the performance of nearly all makes of such systems is higher than that of conventional systems, and further improvements are to be expected. This means that semi-conductor ignition systems have reached the point where contact with "live" parts or contacts (whether on the primary side or the secondary side) can prove fatal.

In this connection we should like to point out to you that the laws valid in your country regarding work on high-voltage systems must be adhered to when working on, or testing, semi-conductor ignition systems.

As a matter of principle, when working on such ignition systems the ignition is to be switched off. Included in such work are the following operations:

- Connection of engine testing equipment (timing light, dwell-tach tester, ignition oscilloscope etc.).
- Replacement of ignition system parts (spark plugs, ignition coil, ignition distributor, H.T. ignition cables etc.).

If it is necessary to switch on the ignition in order to test the system or make adjustments on the engine (to the carburetor for instance), then lethal voltages are present throughout the entire system.

This means that the danger of accident exists not only at individual components in the system (e.g. ignition distributor, ignition coil, trigger box, ignition harness), but also at the wiring harness (e.g. connection for the tachometer, diagnostic connector), on terminals, and on test equipment.

BOSCH

Geschäftsbereich KH, Kundendienst, Kfz-Ausrüstung
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50. Printed in the Federal Republic of Germany.
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH.

N1

Technical Information
Volvo




In addition, in the case of the capacitor-discharge ignition system (CDI), danger of accident is also present under the following circumstances:

- Operation of the trigger box without the ignition transformer.
- At the trigger box, (removed), relatively soon after it has been switched off (capacitor discharge).

Below is a typical terminal diagram of a semi-conductor ignition system, the danger points are marked with red high-voltage arrows. We would point out that all semi-conductor ignition systems, even the older ones, are to be regarded as dangerous in the sense as defined by this bulletin.

Please address any queries or comments concerning the contents of this publication to our representative in your country.



Terminal diagram

After-sales Service

Technical Bulletin

Only for use within the Bosch organization. Not to be communicated to any third party.

EFFECTS OF ELECTRICAL AND ELECTRONIC
SYSTEMS ON HEART PACEMAKERS

VDT-I-227/107 En
1.1981

e.g. ignition systems, Jetronic, Motronic, ABS

Please ensure without fail that this Bulletin is passed on to your employees for their attention!

We have often been asked by some of our customers whether or not patients with heart pacemakers are endangered in any way by ignition systems. This theme was recently the subject of an examination carried out by the Ignition System Development Department of Robert Bosch GmbH in conjunction with Dr. Thull, lecturer at the Central Institute for Biomedical Technology at the University of Erlangen-Nürnberg and Biotronic GmbH & Co. of Berlin, a manufacturer of heart pacemakers. The magazine "Biomedizinischen Technik" (5/80) listed the results.

The most important discoveries in this practice can be summarized from the examination report as follows:-

1. Heart pacemakers corresponding to the latest state of the art are not affected by radiation (electromagnetic fields) from ignition systems.
2. With a stationary engine and the ignition switched off the heart pacemaker is not affected by any part of the ignition system, even when unintentionally touched. Maintenance work in the engine compartment, for example, can then be carried out without any danger.
3. With the engine running or stationary with the ignition switched on, touching current-carrying parts of the ignition system, as well as parts of any other electrical system, presents a certain danger for everybody. The heart pacemaker can here be affected under certain conditions (voltage, current and frequency).
Patients with heart pacemakers should therefore at all costs avoid touching current-carrying parts of electrical systems.
4. Furthermore, patients with heart pacemakers are more inclined to psychic shock effects than other people, even when they receive just a harmless electric shock, because many such patients are conscious of the increased danger to the cardiac activity.

We therefore consider it inadvisable for patients with heart pacemakers to be employed in workshops or on vehicles where ignition systems are being tested or repaired. If any members of your staff have heart pacemakers please carry out the necessary measures.

BOSCH

Geschäftsbereich KH Kundendienst, Kfz-Ausrüstung.
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50. Printed in the Federal Republic of Germany.
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH

N3

Technical Information
Volvo



We would like to add that heart pacemakers are not expected to be affected in any way by interference from other electronic products and systems which we manufacture, such as the Antiskid System (ABS), Jetronic, Motronic, because the much greater radiation intensity of the ignition systems examined in normal use has not caused any interference to heart pacemakers corresponding to the latest state of the art.

If you should receive questions on this matter from customers, please inform them accordingly.

N4

Technical Information
Volvo



After-sales Service

Technical Bulletin

13-39

Only for use within the Bosch organization. Not to be communicated to any third party.

KNOCK SENSOR

0 261 231 ..

VDT-I-227/110 En

3.1983

Procedures for after-sales service

Description


The knock sensor contains an active piezoceramic element. It is screwed to a chosen position on the engine block and sends a structure-borne signal which is processed further by an electronic control unit.

User

Saab is the first vehicle manufacturer to use the knock sensor which is being fitted to various turbo vehicles.

Components

Knock sensor 0 261 231 ... *



* The exact part numbers are given on the appropriate vehicle-equipment microcards AA... .

Service/exchange parts

The knock sensor is a service part and is supplied by Bosch. The remaining components of the knock control are products made by other firms.

Technical documentation

Technical bulletin "New product" VDT-I-227/10 En.

BOSCH

Geschäftsbereich KH Kundendienst, Kfz-Ausrüstung
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50 Printed in the Federal Republic of Germany.
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH.

N5

Technical Information

Volvo



Training

Special training is not necessary.

Retrofitting

The knock sensor is not intended for retrofitting.

Warranty procedure

Components on which a claim is being made should be sent for inspection during the warranty period to our representative in your country. He should forward it to:

ROBERT BOSCH GMBH
KH/LAV - Auspackraum
zur Weiterleitung an K1/VAK2
7000 Stuttgart 30
Federal Republic of Germany

This regulation applies until further notice.



After-sales Service

Technical Bulletin

Only for use within the Bosch organization. Not to be communicated to any third party.

BREAKERLESS TRANSISTORIZED IGNITION SYSTEM

22

Warranty note

VDT-I-227/103 En
3.1979

Hybrid construction trigger boxes

0 227 100 100 for ignition distributor
with Hall generator (TCI-h)
0 227 100 102 for ignition distributor
with induction-type
pulse generator (TCI-i)

Apart from the well-known TCI trigger boxes 0 227 100 0.., trigger boxes of hybrid construction have been fitted as standard since 9.78 (Fig. 1).




Fig. 1

Warranty procedure

If the complaints are justified, all these hybrid trigger boxes are to be sent, along with completed warranty documents, to your authorized representative for forwarding to the following address:

ROBERT BOSCH GMBH
KH/LAV - Auspackraum

zur Weiterleitung an K1/VAK 21

D-7000 Stuttgart 30

This instruction remains valid until further notice.

BOSCH

Geschäftsbereich KH, Kundendienst, Kfz-Ausrüstung
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50 Printed in the Federal Republic of Germany.
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH.

N7

Technical Information
Volvo



After-sales Service

Technical Bulletin

Only for use within the Bosch organization. Not to be communicated to any third party.

NEW DESIGNATIONS FOR IGNITION SYSTEMS

VDT-I-227/108 En

1.1983

The introduction of new ignition systems has made it necessary to reclassify all designations.

The designations listed below will be used immediately in KH workshop and sales literature.

Designation	Abbrev'd code	Meaning	Switching	Ignition control and spark advance	High-voltage distribution
Coil ignition	SZ (CI)	-----	Mechanical (breaker points)	Mechanical (ignition distributor)	Mechanical (ignition distributor)
Transistorized coil ignition	TSZ-K (TCI-c)	K=breaker-triggered	Electronic (trigger box)	Mechanical (ignition distributor)	Mechanical (ignition distributor)
Trigger box with conventional circuit techniques	TSZ-I* (TCI-i)	I=Induction-type pulse generator	Electronic (trigger box)	Mechanical (ignition distributor)	Mechanical (ignition distributor)
	TSZ-H	H=Hall generator	Electronic (trigger box)	Mechanical (ignition distributor)	Mechanical (ignition distributor)
Transistorized ignition	TZ-I* (TI-i)	I=Induction-type pulse generator	Electronic (trigger box)	Mechanical (ignition distributor)	Mechanical (ignition distributor)
(Trigger box in Hybrid technique)	TZ-H* (TI-h)	H=Hall generator	Electronic (trigger box)	Mechanical (ignition distributor)	Mechanical (ignition distributor)

BOSCH

Geschäftsbereich KH, Kundendienst, Kfz-Ausrüstung
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50. Printed in the Federal Republic of Germany.
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH.

N8

Technical Information

Volvo



Designation	Abbrev'd code	Meaning	Switching	Ignition control and spark advance	High-voltage distribution
Breakerless semiconductor ignition with or without knock control	EZ EZ-K	- K=Knock control	Electronic (trigger box or control unit)	Electronic (control unit)	Mechanical (ignition distributor or high-voltage distributor)
Distributorless ignition with or without knock control	VZ VZ-K	- K=Knock control	Electronic (control unit)	Electronic (control unit)	Electronic (dual-spark ignition coil, or 1 ignition coil for each spark plug)

*Note: The ignition system can also be equipped with a DLS unit (digital idle stabilization) or with an ELS unit (electronic idle stabilization) or with an ESV unit (electronic ignition retardation).



After-sales Service

Motor Vehicle Service Information

Only for use within the Bosch organization. Not to be communicated to any third party.

INCORRECT DISPLAY OF ROTATIONAL SPEED AND
DWELL ANGLE ONLY WITH TRIGGER BOXES
0 227 100 ... (TCI-i, TCI-h) WITH CURRENT
LIMITATION

VDT-I-Gen. 030 En
6.80
Supersedes Ed. 3.80

For additional information see VDT-I-Gen. 032 En

1. General

In comparison with conventional ignition systems, transistorized ignition systems with current limitation have different primary voltage characteristics. During the dwell period the voltage at terminal 1 of the ignition coil may assume values from 1.5 V to battery voltage (or greater). This may lead to an incorrect display of rotational speed and dwell angle when testing the ignition system. However, there is no functional defect in the ignition system, and, for this reason, the trigger box must not be replaced. Incorrect displays may occur with the testers listed below:

MOT	001.00}	Rotational-speed
	001.01}	display O.K. with these
	001.02	testers
	001.04	
	002.00	

KTE	001.00
	001.02
	001.03

By now, the following vehicles may be fitted with breakerless ignition systems with current limitation:

Audi	(Bosch/Fairchild- ignition system)
BMW	(Bosch ignition system)
Citroen	(Delco ignition system)
Fiat	(Delco ignition system)
Ford	(Delco ignition system)
General- Motors	(HEI-ignition system)

Mazda	(Mitsubishi ignition system)
Mitsubishi	(Mitsubishi ignition system)
Nissan-Datsun	(Hitachi ignition system)
Peugeot	(Bosch ignition system)
VW	(Bosch/Fairchild ignition system)
Bosch transistorized ignition system for retrofitting 0 227 100 920	

BOSCH

Geschäftsbereich KM Kundendienst, Kfz-Ausrüstung
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50 Printed in the Federal Republic of Germany
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH.

N10

Vehicle Service Information

Volvo



2. Test instructions

2.1 Rotational speed

Incorrect rotational-speed display can be recognized as follows:

If one starts at the idle speed and slowly increases the engine speed, then the incorrect display can be recognized by an abrupt reduction in the rotational-speed display, e.g. from 2400 min⁻¹ to 1200 min⁻¹.

It is, however, possible to attain correct rot.-speed measurements as follows:

Connect a ballast resistor of 0.9 or 1.0 Ohm (see Fig.) in series in the line to term. 15 of the ignition coil (take care not to cause a short circuit). After the rotational-speed measurement, the ballast resistor must be removed (otherwise starting difficulties and misfiring). Connect tester as per operating instructions.

Suggestion for user manufacture

Required parts:

1 ballast resistor 0.9 Ohm

Part No. 0 227 900 002

or

1 ballast resistor 1.0 Ohm

Part No. 0 227 900 101

2 blade receptacles e.g.


Part No. 1 901 355 881

approx. 0.2 m cable, 1.5 mm² e.g.

Part No. 6 210 150 150

2 insulated clips

Commercially available



1 = Battery

2 = Ignition switch

3 = Clips

4 = Blade receptacle

5 = Ballast resistor

6 = Ignition coil

⚡ approx. 400 V

⚡ approx. 25 kV

2.2 Dwell angle

The dwell angle is electronically controlled. A measurement of the dwell angle is no longer performed.

2.3 Ignition point

Is displayed correctly. Connect tester as per operating instructions.



After-sales Service

Motor Vehicle Service Information

Only for use within the Bosch organization. Not to be communicated to any third party.

MOTORTESTER CONVERSION

VDT-I-Gen. 032 En
6.80

Incorrect display of rotational speed,
dwell angle and ignition point
only with trigger boxes
0 227 100 ... (TCI-i, TCI-h) with current
limitation

For additional information see VDT-I-Gen. 030 of 6.80

Re.: Motortester EFAW 268
268 S 10
269
214 B
AE 2000

1. General

Please make sure that the above-mentioned motortesters in your workshop and at your customers (e.g. motor vehicle workshops, oil companies, gas stations, vocational schools etc.) are converted. The conversion is subject to payment and is carried out by the K7 after-sales service of the responsible BG. The standard time is 15 work units (with fitting of switch).

2. Why motortester conversion?

In comparison with conventional ignition systems, transistorized ignition systems with current limitation have different primary voltage characteristics. During the dwell period the voltage at terminal 1 of the ignition coil may assume values from 1.5 V to battery voltage (or greater). This may lead to an incorrect display of rotational speed and dwell angle as well as to incorrect triggering of the meter when testing the ignition system. There is, however, no functional defect in the ignition system, and, for this reason, the trigger box must not be replaced. Since, with the above-listed motortesters, the timing light is triggered by the signal path dwell angle - meter, this incorrect triggering also leads to incorrect flashing and thus to an incorrect display of the advance angle.

3. Conversion measures

The situation is to be remedied by modifying the wiring of the testers so that the timing light is triggered by the clamp-on induction pickup and the pulse shaper stage.

BOSCH

Geschäftsbereich KH: Kundendienst, Kfz-Ausrüstung
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50 Printed in the Federal Republic of Germany
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH.

N12

Vehicle Service Information

Volvo



4. Test instructions

4.1 Standard ignition systems

Switch position: "standard"

All other tester connections as per operating instructions.

4.2 Ignition systems with current limitation

Switch position: "current limitation"

In order to trigger the timing light, the induction-type pulse generator (clamp-on pickup or red pickup) must always be connected during the measurement.

The selector switch for ignition systems built into the motortester must be switched to standard coil ignition (not to TCI) with these ignition systems.

All other tester connections as per operating instructions.

The dwell angle is electronically controlled. A measurement of the dwell angle is no longer performed.



After-sales Service

Motor Vehicle Service Information

Only for use within the Bosch organization. Not to be communicated to any third party.

TESTS ON ELECTRONIC IGNITION SYSTEMS
(TCI, TZ)
TESTER INSTRUCTIONS

VDT-I-Gen. 035 En
3.1981

The following tests are listed in older and current Tester operating instructions or in Trouble-shooting with the oscillograph:

- "Separate ignition coil test" (concerns EFAW 213, 214, 268, AE 2000).
- Calculating the "ignition voltage reserve" (concerns EFAW 213, 214, 268, AE 2000 and MOT series).
- "Intensified insulation test" (concerns EFAW 213, 214, 268, AE 2000 and MOT series).

Nowadays transistorized ignition systems deliver more than 30,000 V secondary voltage.

To avoid damage to ignition coil, ignition cable and ignition distributor by voltage flashovers, the tests listed above should not be carried out on transistorized ignition systems.

The contents of this Service Information has already been published in the K7-Information K7-VJF 17/8012.

BOSCH

Geschäftsbereich KH Kundendienst Kfz-Ausrüstung
© by Robert Bosch GmbH, D-7 Stuttgart 1, Postfach 50 Printed in the Federal Republic of Germany
Imprimé en République Fédérale d'Allemagne par Robert Bosch GmbH

N15

Vehicle Service Information

Volvo



TABLE OF CONTENTS

<u>Section</u>	<u>Coordinates</u>
Layout of microcard	A 1
1. Special features	A 2
2. Test values	A 2
3. Wiring diagram	A 4
4. Component locations	A 6
5. Required test instruments and tools	A 15
6. Incorrect speed, dwell angle and firing point display	A 16
7. Hazards in electronic ignition systems .	A 16
8. Important vehicle information	A 20
9. Troubleshooting	B 1
Self-diagnosis system	B 5
Troubleshooting chart	B 9
Comprehensive troubleshooting sequence if both primary signal and ignition spark are present	B 15
Comprehensive troubleshooting sequence if <u>no</u> primary signal or <u>no</u> ignition spark is present	E 1
<u>Technical Information:</u>	
Hazards	N 1
Effects of electrical and electronic systems on heart pacemakers	N 3
Warranty information	N 5
Warranty information	N 6
New designations for ignition systems	N 8
<u>Vehicle Service Information:</u>	
Incorrect speed and dwell angle display	N 10
Conversion of engine tester	N 12
Testing of electronic ignition systems	N 15



© Robert Bosch GmbH
Automotive Equipment - After-Sales Service,
Department for Technical Publications KH/VDT,
Postfach 50, D-7000 Stuttgart 1

Published by: After-Sales Service, Department for
Training and Technology (KH)VSK). Press date: 5.1984.

Please direct questions and comments concerning the
contents to our authorized representative in your
country.

This publication is only for the use of the Bosch
After-Sales Service Organization, and may not be passed
on to third parties without our consent.

Microfilmed in the Federal Republic of Germany.
Microphotographié en République Fédérale d'Allemagne.

